

Brake Pad Bedding Procedure

1. On the track or suitable location, slowly engage brake system approximately 10 times while driving at medium speed, slowing the car but not coming to a complete stop.
2. Continue driving at medium speed with no brake engagement for approximately 2 or 3 minutes allowing brake pads to cool down.
3. Repeat step 1 while slowly increasing driving speed.
4. Repeat step 2.
5. Begin driving car and engaging brake system as in race conditions for approximately 5 laps.

After completing above steps allow brake system to completely cool down before any additional brake use (parking car during cool down is recommended). Brake pads should now be race ready!